



Power From Mains

Connect the Mains supply and the "Power" indicator (3) will light.

Power From Rechargeable Battery (/R factory fit option)

If the rechargeable battery is fitted, charging is automatic when Mains is connected. It cannot be overcharged. When the rechargeable battery is low, the power light (3) will flash. The battery must be charged for approximately 6 to 8 hours to reach full charge. The rate at which this battery discharges is dependent on its original state, volume setting and use of cassette mechanism (rewind/fast forward requires more power).

WARNING -The life of a rechargeable battery is shortened by over discharging and not immediately recharging. If left in a discharged state, the battery can be permanently and irreversibly damaged.

Cassette Mechanism

The cassette mechanism has Cue and Review on playback and full Autostop giving key reset and motor stop at end of tape on all functions.

NOTE:

- (i) It is important to keep the pinch wheel and heads clean in the usual manner to ensure good trouble free performance.
- (ii) The 390 Player will not record; if the RECORD key is pressed it will only play.

To Play a Recorded Cassette

Use VOLUME (1) and TONE (2) to adjust sound.

Headphone Sockets (4)

Up to 5 pairs mono or stereo headphones may be connected. Connecting a pair to the MASTER socket automatically disconnects the internal loudspeaker.

External Loudspeaker Socket (5)

- a) For external and internal loudspeakers operating together - minimum external impedance 8 ohm.
- b) For an external loudspeaker only - minimum external impedance 4 ohm.

Remote Socket (6)

A foot control with mini jack can be connected to socket (6) for remote stop and start operation.

Track Selector (7)

This enables Audio Track, A, Time Base Track, B, or Both tracks to be selected.

SAFETY & GENERAL INFORMATION

Headphones: For personal safety and comfort connect headphones into equipment, turn volume down and then switch on **before** placing headphones over ears. For safety use only 600 ohm headphones (i.e Coomber type 1929).

Environments: The equipment should not be exposed to dust, moisture, water, chlorine and other corrosive substances in normal use or during storage. It will cause damage to this equipment.

Swimming pool atmospheres: are very hostile to all electro-mechanical equipment (e.g. steel rusts and rubber perishes). Equipment returned for repairs showing evidence of use in adverse environments may, at our discretion, be charged for even during the 12 month warranty period.

- Rechargeable battery replacement must be carried out by a competent qualified technician.
- The disposal of batteries (rechargeable or otherwise) where used in Coomber equipment should be discarded in accordance with local regulations.
- Do not cover the ventilation openings with any items (e.g. newspaper, fabrics etc.)
- Naked flames, such as lighted candles, should not be placed on or near the apparatus.
- The apparatus should not be exposed to dripping or splashing. No objects filled with liquids, such as vases, should be placed on or near the apparatus.

European Safety Standard: All Coomber equipment complies with EN60065. Any local requirements for use of this equipment should be taken into account.

Class II construction - electrical safety

Mains Voltage

UK & EEC: 220-240V 50Hz Mains Cable: Line - Brown, Neutral - Blue
USA: 110-120V 60Hz Mains Cable: Line - Black, Neutral - White

Isolate from mains supply when not in use by removing the plug from the wall socket.

Mains Plug: The mains cable fitted to this equipment is already provided with a moulded plug. If another plug type is required, follow instructions from the plug manufacturer, or seek advice from a qualified person. DISPOSE OF ORIGINAL PLUG SAFELY. DO NOT RE-USE.

Mains Plug fuse rating: 3Amp to BS1362 (applicable in UK)

Model type and rating information is located on a label on the base of the product.

Additional Technical Information: If you require any further help or information, or if any point is not clear, then please telephone 01905 342070 quoting your model number and serial number (located on a label on the rear of the product). Our Technical Department will be pleased to help you.

Note: This equipment contains no user serviceable parts and should only be dismantled by competent qualified personnel. Dismantling will render the warranty void.

Electrical Safety Testing:

- Safety testing and servicing should only be carried out by competent qualified personnel.
- The supply cable is part of a special assembly. If damaged the equipment should be returned to Coomber Electronic Equipment Limited or their agent for cable replacement.

Coomber Electronic Equipment Ltd.

Brindley Road, Warndon, Worcester, WR4 9FB, U.K.

Tel: 0044 (0)1905 342070

Fax: 0044 (0)1905 759170

e-mail: sales@coomber.co.uk

web: www.coomber.co.uk

- Coomber reserve the right to change products and specifications without notice.
- All Coomber equipment is covered by a 12 months warranty against defective components or faulty manufacture from date of dispatch. Any modifications to or misuse of the equipment renders this warranty void.
- Equipment that is security marked or damaged cannot under any circumstances be exchanged.